



## Optisol KP - S Cleanliness Solution

Today's technologies require high cleanliness for air, land or sea. Precision cleaning is required in a variety of today's industrial technology applications. Kemet cleanliness solution offering development parallels today's applications' increasing challenges.

Kemet is known worldwide as an expert in industrial cleanliness solutions. With 30 years accumulated expertise, we are focused to providing an effective cleanliness solution to the most demanding industrial parts cleaning applications. Our cleanliness solution is achieved with minimal process turnaround time, reduction to process costs and is environmentally friendly.

### Vacuum Cleanliness Technology

Optisol KP - S is based to the expertise in the vacuum cleanliness solutions utilizing chlorinated solvents. The Optisol KP - S system is specifically designed for industrial precision parts cleaning. The completely encapsulated solution operates constantly under vacuum providing an excellent solution to achieving a high cleanliness result while imposing no harmful effects to the environment.



The single cleaning chamber is utilized for all stages of the cleanliness cycle including spray cleaning, immersion cleaning, optional ultrasonic cleaning, rinsing, drying and optional rust inhibitor application.

### Applications

Optisol KP - S is a modular design to precision cleanliness applications. Industries utilizing Optisol KP - S requiring precision cleanliness are numerous and some include:

- Aviation; service and manufacturing
- Cryogenics, high vacuum
- Electronics and computer manufacturing
- General manufacturing industry
- Pharmaceutical industry
- Polishing industry
- Precision component manufacturing
- Hydraulic and pneumatic industries
- Manufacturing of fittings

#### **Kemet International Limited**

Parkwood Trading Estate, Maidstone, Kent, ME15 9NJ, UK

Tel: 01622 755287; Fax: 01622 670915

Email: [sales@kemet.co.uk](mailto:sales@kemet.co.uk); Web: [www.kemet.co.uk](http://www.kemet.co.uk)

## Optisol KP - S Design

Precision cleaning solutions are demanded in a variety of manufacturing industries utilizing solvents. The single cleaning chamber solution is especially suited to precision cleaning of diverse metal, electro-mechanical devices, sintered materials, press-cut sheet-metal components, bearings, and components under overhaul/maintenance treatment. Contaminants to be removed are typically oils, swarf, polishing and grinding compounds, rust or particles.

Optisol KP - S concept consists of articles requiring cleanliness being contained in metallic baskets with proper perforation for complete discharge of contaminants and solvent through the cleaning process.

## Operation and Maintenance

Optisol KP - S is easy to setup and operate with minimal maintenance requirements. Teleservice link capability is an available option for remote diagnostic functions. Line connection is the responsibility of the customer.

## Materials

All tanks are of stainless steel construction, support frame and panels are of painted steel. Overall system is made to assure proper operation under vacuum conditions. The electric cabinet is installed into the main system housing. Submersible ultrasound transducer boxes, liquid valves, heating elements and level switches are of acid-proof steel to assure long and trouble free operation.

## Optisol KP - S Features

### Control Panel

The Optisol KP - S is equipped with an electrical control cabinet which houses high quality electric and electronic components for power supply, emergency services, control and switching and is conveniently located in main system housing next to the loading/unloading door. All general monitoring devices and controls are available on the front control panel.

If the system is equipped with an automatic sliding door and baskets feeding system, the operating panel and control buttons are located on a control pedestal adjacent to the system.



### Load/Unload Door

Access to the cleaning chamber is by means of a rigid load/unload door. The baskets are loaded to and unloaded from the cleaning chamber and when the door is properly closed and locked by the standard safety interlock system the wash cycle may commence.

The door is locked by means of a pneumatically operated cylinder to prevent opening during the wash cycle. A safety limit switch is installed to the door hinge for assuring proper positioning of the hatch in closed position.

### Kemet International Limited

Parkwood Trading Estate, Maidstone, Kent, ME15 9NJ, UK

Tel: 01622 755287; Fax: 01622 670915

Email: [sales@kemet.co.uk](mailto:sales@kemet.co.uk); Web: [www.kemet.co.uk](http://www.kemet.co.uk)

### **Automatic Sliding Load/Unload Door (option)**

For automatic access with vertical movement, an optional automatic load/unload door with vertical pneumatic cylinder is available. This is of particular use when ordering optional automated loading and unloading equipment.



### **Cleaning Chamber**

The cleaning chamber is a fully sealed stainless steel pressure chamber consisting of rotary basket frame with sliding hook to extract the basket from the longer chambers, pipe for spray jets at the top of the chamber, optional pipe for hydrokinetic (submerged) jets at the bottom of the chamber and optional ultrasound transducer boxes.



Movement of the baskets during the cleanliness cycle is fully programmable to ensure full drainage of solvent, particularly in the vacuum drying stage. In addition, the movement also provides maximum washing efficiency and removal of solids from the washed components. For loads with more sensitive components without cavities or blind holes on the top which may trap solvent which cannot be secured in the basket, a static cleanliness cycle with none or limited movement may be selected. Basket movement (static, tilting at different, programmable angles or rotation) can be easily selected at the control panel.

### **Solvent Storage Tank**

The solvent storage tank is located on the bottom of the unit, below the cleaning chamber and is divided up to four (4) sections: 1) spray pre-cleaning; 2) spray cleaning (optional); 3) immersion cleaning, and; (4) rust inhibitor spray (optional).

Each section has an inspection window, a level sensor and a series of automatic valves that open/close after completion of the various steps as defined in the program for the selected cleaning process. The third and fourth sections are heated by electrical heaters directly immersed in the solvent.

### **Vacuum Pump**

The Optisol KP - S operates in a single encapsulated cleanliness solution constantly under vacuum. The vacuum is generated to the level of 50 mbar by means of a oil lubricated vane vacuum pump system.

### **Distillation Circuit**

The distillation circuit provides solvent cleaning by means of continuous loops of vapour boiler and distillation loop. Clean solvent is then returned to the solvent tank. The distillation circuit requires regeneration when the saturated solvent in boiler alarm appears and takes approximately 4 hours on a normal system. For continuous 24/7 operation, an optional external distillation circuit is available.

### **Kemet International Limited**

Parkwood Trading Estate, Maidstone, Kent, ME15 9NJ, UK  
Tel: 01622 755287; Fax: 01622 670915  
Email: [sales@kemet.co.uk](mailto:sales@kemet.co.uk); Web: [www.kemet.co.uk](http://www.kemet.co.uk)

### **Sludge Separator (option)**

For further distillation of the sludge (oil and solvent mixture) the optional sludge separator is available. To maintain degreasing capacity, it is useful to periodically reduce the amount of oil in the cleaning solvent. This is achieved by transferring solvent from the main boiler to the sludge separator where the sludge is then heated to separate solvent from the oil. The solvent is then condensed and returned to the tank.

Residual sludge primarily created from oil can then be transferred to an external vessel for proper disposal.

### **Active Carbon Filter**

After the distillation process, all valves in the system close and solvent gathers to the heat exchanger, vapours condense and residual traces of solvents then pass through the active carbon filter. The system includes automatic regeneration cycle for the active carbon filter. For 24/7 operation, an optional external active carbon filter is available.

### **Coarse Filter**

From the cleaning chamber the solvent flows by means of a centrifugal pump that provides each the loop chamber to chamber flow and the transfer to the storage tank. During either flow process the solvent passes through a bag filter which traps chips and other metallic contaminants and particles of any material. An alarm will trigger in the wash cycle when the coarse filter requires cleaning.



### **Cooling Systems**

Optisol KP - S has cooling systems for safety of temperature control. A feed from sensors will activate the step by step cool down and if needed a complete shut down of the system will occur. Machine is equipped in several safety circuits to minimize explosion hazard.

### **Process control (standard)**

The Optisol KP - S process control offers flexible automation control for the entire cleaning system. The control features a touch screen Graphic User Interface (GUI). Through the GUI operator can activate various pre-programmed cleaning cycles or produce and save even cleaning program cycle.

Each process stage is programmable through the process control; also each stage status can be displayed at anytime on the process control. The number of cleaning programs is virtually unlimited in the process control; any of the pre-programmed cleaning programs can be queued for achieving a continuous automated process.

Parameters that are programmable for up to 4 treatments in 1 washing cycle include the following:

- ◆ Treatment time for each stage for spray, hydrokinetic or (optional) ultrasound
- ◆ Type of basket movement (stationary, oscillation or rotation)

### **Kemet International Limited**

Parkwood Trading Estate, Maidstone, Kent, ME15 9NJ, UK

Tel: 01622 755287; Fax: 01622 670915

Email: [sales@kemet.co.uk](mailto:sales@kemet.co.uk); Web: [www.kemet.co.uk](http://www.kemet.co.uk)

- ◆ Drain time for each stage
- ◆ Complete draining from pump, filter and pipes of residual solvent after elapsed time for wash 4
- ◆ Dirty coarse filter alarm time
- ◆ Pump delayed start time
- ◆ Time out pump
- ◆ Rush inhibitor treatment time
- ◆ Filling time for wash cycles 1 through 3
- ◆ Minimum level in boiler
- ◆ Vaporization time
- ◆ Vaporization drain time
- ◆ Vacuum drying time
- ◆ Deodorizing time
- ◆ Maximum level in total draining vessel

Safety features are monitored on continuous basis by the process control and operation is halted if serious alarm or operator is warned when such situation occurs.

### **Ultrasonic Cleaning (option)**

Optisol KP - S may also have the optional integrated ultrasonic cleanliness as a step in cleanliness cycle where appropriate application requires. Ultrasonic cleaning is immersion cleaning, based to high frequency sound vibrations which cause strong cavitations in the liquid. The microscopic cavitation bubbles implode the surface of the work piece removing contaminants by means of powerful pressure strokes. Ultrasonic cleaning will penetrate any channel or hole where the liquid can reach.

### **Rust Inhibitor Tank (option)**

The optional rust inhibitor tank is available where specific applications require such process. This is integrated as part of the cycle in the cleaning chamber and fully programmable through the PLC control.

### **Fine Filtration System (option)**

For an additional filtration beyond the active carbon and coarse filters, the fine filtration system option can be added to the Optisol KP - S.

### **Water Chiller for Safety Cooler Circuit (option)**

An optional external water chiller for the safety cooler circuit can be integrated into the cleanliness system.

### **Additional Carbon Filter Circuit (option)**

The carbon filter when saturated will give an alarm and regeneration of the carbon filter averages between 3 to 4 hours and may be required anywhere from 2 times per week to daily depending upon conditions. For uninterrupted 24/7 operation of the Optisol KP - S, the optional additional carbon filter circuit is recommended.

### **Kemet International Limited**

Parkwood Trading Estate, Maidstone, Kent, ME15 9NJ, UK  
 Tel: 01622 755287; Fax: 01622 670915  
 Email: [sales@kemet.co.uk](mailto:sales@kemet.co.uk); Web: [www.kemet.co.uk](http://www.kemet.co.uk)

### External Distiller Unit (option)

A complete cleaning (regeneration) of solvent can normally be made in approximately 4 hours under normal system conditions via a distillation cycle during off working hours. For uninterrupted 24/7 operation of the Optisol KP - S, the optional external distiller unit is recommended. In addition, the addition of the external distiller unit will reduce solvent consumption.

### Automatic Basket Transport System (option)

Optisol KP - S can be equipped with a variety of automated basket transport systems depending upon your requirements. Automation options include the following:

- Basket lift is available from lower level such as transport cart to cleaning chamber level for manual insertion/extraction to and from the chamber. Lifting device is attached to the frame of the machine.



- Conveyor system is available for buffering dirty baskets for transport to the machine and exit to clean basket buffer. Buffer conveyors can be customized to length based to standard feed system module.

- Multi machine automation is available from single dirty basket buffer system connected to a wagon system which moves the baskets to machine. Automatic program selection can be accomplished by identification system to the baskets.



- Basket handling system can be designed to handle stacks of baskets.

### Kemet International Limited

Parkwood Trading Estate, Maidstone, Kent, ME15 9NJ, UK

Tel: 01622 755287; Fax: 01622 670915

Email: [sales@kemet.co.uk](mailto:sales@kemet.co.uk); Web: [www.kemet.co.uk](http://www.kemet.co.uk)

## Optisol KP – S model

	KP 50 S	KP 100 S	KP 150 S
<b>Overall dimensions (mm )</b>			
Width	1750	1750	1900
Depth	1750	2150	2150
Height	2600	2600	2600
<b>Basket capacity</b>			
Length ( mm )	450	600	900
Width ( mm )	300	450	450
Height ( mm )	200	200	200
Weight ( kg)	50	100	150
<b>Cycles/hour</b>			
Depending on cleaning process and treatment times	Up to 5	Up to 5	Up to 5
<b>Power requirements</b>			
Standard system	3 x 400 V / 50 Hz	3 x 400 V / 50 Hz	3 x 400 V / 50 Hz
Total load (kW approx)	17	25	33
<b>Cleaning fluid</b>	Chlorinated solvents	Chlorinated solvents	Chlorinated solvents
	PCE, TCE	PCE, TCE	PCE, TCE
<b>Capacity of the system (litres)</b>			
Tank 1 ( spray )	40	60	60
Tank 3 ( immersion )	100	150	200
Rust inhibitor tank (spray option)	40	60	60
Distillation unit	80	130	150
Solvent capacity ( approx )	260	400	450
<b>Empty Weight of the machine</b>			
Kg	1400	1800	2400

Data herein is for estimation purposes only and can be changed at any time without any prior notice.

### Kemet International Limited

Parkwood Trading Estate, Maidstone, Kent, ME15 9NJ, UK

Tel: 01622 755287; Fax: 01622 670915

Email: [sales@kemet.co.uk](mailto:sales@kemet.co.uk); Web: [www.kemet.co.uk](http://www.kemet.co.uk)